

Temperature measurement in e-mobility

CSM Web Seminars




Temperatures

are the most acquired measurement in vehicle technology.

Make up 70% measurement channels sold.



Temperature measurement in e-mobility





Temperature measurement in e-mobility

Test bench and road test

Verification of simulations under real conditions



Sensor technology for temperature measurements

	Thermocouples	PT100 / PT1000 RTD elements
+	Accuracy: approx. ±1.5 K or 0.4 % of measured value (class 1)	Very good accuracy: approx. ±0.15 K (Class A)
	Wide measuring range: -40 °C to +1,000 °C (Class 1)	Sufficient measuring range: -200 °C to +650 °C (class A)
	Easy handling	Low susceptibility to interference
	Good response times	
_	Design depending on application	Complex cabling (4-wire)
	Susceptible to interference	Active power supply
		Slow response times
	All contacts must be made of thermal material for accuracy	Decreasing measurement accuracy with increasing temperature



Sensor technology for HV environments

Thermocouples

PT100 / PT1000 RTD elements



Conventional sensor technology in the HV environment?



Temperature measurements also possible with conventional sensor technology




But:

- ► HV-safe cables
- HV-safe connectors
- HV-safe measuring devices incl. power supply



Use of standard measurement technology - Danger to life

Unsuitable and dangerous temperature measurement chain






HV-safe sensor technology


Benefits with thermocouples

- Many individual variants of measuring tips possible
- ► FEP orange 1000v contact protection sheathing
- 2-wire, 4 temperatures on HV sum socket
- Various installation options, e.g. with very good temperature-conductive Kapton adhesive pad
- ► Temperature range (Class 1): -40 °C to +1,000 °C



Benefits with PT100 / PT1000 RTD sensors


- Very thin films possible (≤0.7 mm)
- Very high accuracy of the entire system incl.
 measuring module achievable (up to approx. ±0.3 K)
- Very good long-term stability





HV-safe sensor cables

Using the example of a type K thermocouple







HV-safe sensor cables

Typical 8-wire sensor cables

- ▶ Good ratio between outer protective sheath, warning inner sheath, pair or bundle sheath and strands
- Still sufficiently thin and flexible
 - Single wires 1,000 V touch-proof




Thermo cable



PT100 cable



HV-safe measurement chain for temperature measurements





"Standard" measurement module

Connector

A special HV-safe connector concept is required:

- Features
 - Connector system (plug, socket) type-tested according to safety standard EN 61010-1:2010 to 1,000 V DC working voltage
 - Clearance and creepage distances >8 mm (when mated)
 - Fire protection class V 0, i.e. self-extinguishing after 5 sec
 - Waterproof (protection class IP67)
 - Suitable for many mating cycles >1,000
 - Connections potted in plug and in module
 - Cover cap for protection


The connector must not be assembled by the customer.







HV-safe measurement chain for temperature measurements






HV Isolation inside Measurement Modules



Example: of the CSM HV TH4 evo thermo measuring module







HV-safe measurement equipment

Example: CSM HV thermo modules (thermocouples)



- 4 or 8 NiCr-Ni (Type K) temperature channels
- Operating altitude: max. 5,000 m above sea level
- Operating temperature range: -40 °C to +125 °C
- IP65 / IP67
- Very high measuring accuracy







- HV-safe connector
- Mechanical connector guide for tightness and bend protection
- Reinforced insulation: 1,000 V RMS
 - Channel / channel, channel / CAN, channel / power supply
- Type-tested according to safety standard EN61010 by accredited test laboratory
- Unit test with certificate
- 3,100 V ramp each 5 sec







HV-safe measurement equipment

Example: CSM HV PT modules (RTD sensors)



- 2 or 8 PT100/PT1000 temperature channels
- 4-wire technology, i.e. 2 inputs per HV-safe connector
- Input of individual PT coefficients for best possible adjustment to the sensor
- Extremely high measuring accuracy








- HV-safe connector
- Mechanical connector guide for tightness and bend protection
- Reinforced insulation
 - Channel / Channel, Channel / CAN, Channel / Power supply
- Type-tested according to safety standard EN61010 by accredited test laboratory
- Unit test with certificate
- 3,100 V ramp each 5 sec






HV-safe measurement chain for temperature measurements








Application







Measuring Shield Currents and Temperatures







Temperature and Power measurement in Fuel Cell


Fuel Cell Stack with Media Supply **High-Voltage Electrical System** Hydrogen Tank Hydrogen node Recirculation Blower DC/DC-Flow Converter HV BM 1.1 AD4 pro MC10 Inverter E-Motor HV BM 1.2 DC DC 700 V 0000 00 **HV BM 1.2** Anode Temperature DO H Membrane HV TH8 evo DC 400 V Cathode **HV BM 1.2** DC 700 V Flow Fuel Cell ECU Humidity DC **HV BM 1.1** Pressure **HV AD CAN HV Power HV Traction Battery Distribution Unit** Compressor Air CAN EtherCAT CAN CAN EtherCAT CAN Fuel Cell-Electric Drive Electric Vehicle-Power Train **XCPoE Vector VX** 00000000



Test Bench

XCP-Gateway

Application: Temperature & voltage measurement in power electronics






Application: Temperature & voltage measurement in power electronics


For the validation of power control units

- Typically 16 40 temperatures are acquired on the various electronic components in the control unit
- Additionally the switching voltages are measured
- Daisy chain all modules on 1 CAN Bus






Application: Thermal characterization of high-voltage batteries







Temperature Measurement and Power in High-Voltage Batteries





Application: Thermal characterization of high-voltage batteries

Temperature measurement at battery module level

Temperature measurement at battery level

- Busbars
- Charging electronics
- BMS
- Other components



Temperature measurement at cell level


Important:

- Exact and reproducible positioning of sensors between individual battery cells
- Extremely high measurement accuracy

A total of 50 to >500 measurement points









- Digital temperature measurement system
- Up to 512 sensors per measurement system
 - One HV Safe Sensor Cable
- Measuring accuracy (total system):
 - ± 0.1 K




IC temperature single sensors and flexible circuits on digital data bus inside battery



- Miniaturized, highly accurate, robust
- Highly interference-resistant (every incoming measured value is correct)
- Exact sensor location and clearly identifiable









HV DTemp Controller

- Required measurement electronics inside the battery (controller)
- Miniaturized and HV-safe







HV DTemp Controller

- Up to 8 controllers cascaded
- One HV-safe cable to the outside




www.csm.de

HV DTemp-P Central Unit

CAN bus central unit for up to 512 sensors




HV safety up to 1,000 V RMS



- IC sensors encapsulated
- Sensor cables 1,000 V touch-safe
- Controller: separate ports
- HV-safe sensor cable to central unit



HV-safe measurement chain and HV DTemp Measurement System





About CSM

CSM has been setting technological standards for decentralized measurement technology in vehicle development for over 35 years. Our CAN bus and EtherCAT® measurement devices support worldwide renowned vehicle manufacturers, suppliers and service providers in their developments.

Continuous innovation and long-term satisfied customers are our guarantee for success. Together with our partner Vector Informatik, we have developed an easily scalable and powerful E-Mobility Measurement System for hybrid and electric vehicles and are constantly expanding the areas of application. With our high-voltage safe measurement systems designed for fast and synchronous measurements and power analyses, we actively accompany the change to E-Mobility.

CSM GmbH (Germany, International)

Raiffeisenstraße 36 70794 Filderstadt

Phone: +49 711 - 77 96 40

email: sales@csm.de

CSM Products, Inc. USA (USA, Canada, Mexico)

1920 Opdyke Court, Suite 200

Auburn Hills, MI 48326

Phone: +1 248 836-49 95

email: sales@csmproductsinc.com





For more information and the current dates of CSM Xplained, please visit

www.csm.de/webseminars



